




San Diego, CA 92110 USA
www.ecr4kids.com

**Doodle
Dry-Erase Desk**
ELR-15328







WARNING:

- ▲ Small parts and sharp points may be present prior to assembly.
- ▲ Adult Assembly required.
- ▲ Do not stand, sit, kneel, climb, lean or pull on unit for support.
- ▲ Use on level, smooth surface.
- ▲ Adult supervision is required at all times.
- ▲ Indoor use only.

PARTS LIST

BEFORE ASSEMBLING, MAKE SURE YOU HAVE ALL THE PARTS



We appreciate your purchase of the Doodle Dry-Erase Desk. ECR4KIDS has made every effort to supply a quality product that with proper use and care, will provide many years of trouble-free use.

If you experience any difficulties with this product, please email us at ecrcs@ecr4kids.com or call (619) 323-2005 (Monday - Friday, 7:00am - 4:00pm Pacific Standard Time)
Please do not return to place of purchase as ECR4KIDS will replace defective part(s) and/or product.

Warranty: Visit our website for product specific warranty information at: www.ecr4kids.com

Care and Cleaning: Clean unit with damp cloth or sponge using warm water and mild soap. Wipe dry. Do not use abrasive cleaners, bleach, chemical solvents, and strong detergents. Do not place near heat, moisture or vaporizer which may cause wood to warp and peel. Check for loose or worn parts periodically and tighten or replace as necessary.