

Product Guide

Helping Hand Two Step Stool ELR-17429

IMPORTANT INFORMATION

Read all instructions before beginning assembly. Keep instructions for future use.

SUGGESTED USE

- ALWAYS ensure the stool is on a flat and level surface during use.
- Perfect for home, school or daycare use.
- Wooden two step stool helps kids and toddlers reach new heights in the kitchen, bathroom, near the bookshelf and more.
- Non-slip steps helps kids keep their footing as they go up and down.
- Natural birch plywood complements any home, classroom, or daycare environment.
- Age rating: 2 years +
- Weight capacity: 150 lb.

⚠ WARNING

- ▲ Adult supervision required.
- ▲ Adult assembly required.
- ▲ Sharp parts and sharp points may be present prior to assembly.
- ▲ Indoor use only.



Assembly

Stools is ready to assemble. All hardware and instructions for adult assembly included.

Maintenance

Check for worn pieces or breakage periodically. Remove the product from service when any condition develops that might deem operation unsafe.

Construction

Sturdy and durable the stool is made of birch plywood.

Care and Cleaning

Clean wood with a damp cloth or sponge using warm water and mild soap. Wipe dry.

Do not place near heat, moisture, or vaporizer which may cause wood to warp and peel.

Items are not waterproof.

Registration & Warranty

Get the most out of ECR4Kids products by registering at www.ecr4kids.com/registration.

5-year limited warranty.



Customer Service



ECR4Kids, L.P.
2245 San Diego Avenue, Suite 125
San Diego, CA 92110
United States



619-323-2005
option 1 for customer service



Customer Service
ecrcs@ecr4kids.com
Sales & Marketing
sales@ecr4kids.com
General Inquiries
info@ecr4kids.com

ECR
4 KIDS
www.ecr4kids.com