

#### Colorful Essentials Play Microwave Oven Model# ELR-0749-A





## **WARNING:**

#### Adult Assembly Required.

Two adults recommended.

- Contains small parts, sharp points and edges.
- Do not stand, sit, kneel, climb, lean or pull on unit for support.
- Never leave children unattended.
- Do not place unit near high heat or moisture.
- Adult supervision recommended.






### Install the Left Side Panel to Top/Bottom Panels

Install the Left Side Panel (A1) onto the Top Panel (B) and Bottom Panel (C) with four Hex Screws (I) using the Hex tool.


<u>Two Adults Recommended</u>: Carefully rotate the onto the **Left Side Panel (A1)**.



## Connect the Shelf

Install two Cam Posts (K1) into the threaded plastic inserts on the inside of the Left Side Panel (A1) with a Phillips screwdriver. This step will be repeated on Right Side Panel (A2).

**Reminder:** Do not overtighten, as the plastic threads can be stripped.




Place four **Cam Locks (K2)** into the recessed holes on the underside of **Shelf (D)**, with the arrow facing the closest edge.

Lower the Shelf (D) onto the Cam Posts (K1) on the Left Side Panel (A1). Turn the Cam Locks clockwise with a Phillips screwdriver to lock the Shelf onto the posts.


# Slide the Back Panel into place

Slide the Back Panel (H) into the grooves on the Top Panel (B) and Bottom Panel (C), until fully seated in the groove on the inside of the Left Side Panel (A1).




### Insert the Front Panel

Insert the pre-installed wooden dowels on the **Front Panel (E)** into the corresponding holes on the underside of the **Top Panel (B)** and topside of **Shelf (D)**.



# 6 Install the Right Side Panel

Lower the **Right Side Panel (A2)** so the **Cam Posts (K1)** align into the holes on the edge of **Shelf (D)**. Turn the **Cam Locks (K2)** clockwise with a Phillips screwdriver to lock the Shelf onto the posts.




Install the Right Side Panel (A2) onto the Top Panel (B) and Bottom Panel (C) with four Hex Screws (I) using the Hex tool.

Two Adults Recommended: Carefully rotate the unit upright.

## 7 Install the Door

Install the **Door (F)** with three **Phillips Screws (J)** using a Phillips screwdriver.





We appreciate your purchase of the CE Play Microwave. ECR4KIDS has made every effort to supply a quality product that with proper use and care, will provide many years of trouble-free use.

If you experience any difficulties with this product, please email us at ecrcs@ecr4kids.com or call toll-free at (855) ECR-4KIDS (Monday - Friday, 7:00am - 4:00pm Pacific Standard Time)

**Please do not return** to place of purchase as ECR4KIDS will replace defective part(s) and/or product.

**Warranty:** Visit our website for product specific warranty information at: www.ecr4kids.com

#### **Care and Cleaning**

Clean unit with a damp cloth or sponge using warm water and mild soap. Wipe dry.

Do not place near heat, moisture or vaporizer which may cause panels to warp and peel.

Check for loose or worn parts periodically and tighten or replace as necessary.

Record the manufacture date here. Information is located on the Batch ID sticker and on the shipping carton. Save this sheet in an accessible place.

Model Number: ELR-0749-A

Factory Code: EG

Manufacture Date:

Batch ID Number: \_\_

(Located on Part C)

©2012 ECR4KIDS, LP

Version: ELR-0749-A 2012.10.29